

GUTTER KIT MAJOR CARPORT (2.5 Mt LEG)

Allowing approximately an 1" fall towards outlet, fix gutter brackets, outlet and gutter joiner with self tap screws. On non outlet end put bracket approximately 115mm (6") from end and the remainder, position equally. Clip gutter into brackets, checking that at outlet end it is pushed only as far as the marked line, to the right and position small gutter extension to the left. Push stop ends in place.

Position down pipe, and trim to required length then fix with round brackets using self tap screws. Push on shoe.

GUTTER KIT-MAJOR 2.5 LEG

- (1) 2 2000mm Gutter
- (1A) 1 1475mm Gutter
- (1E) 1 130mm Small Gutter Ext
- (2) 4 Gutter Brackets (Fix with two screws)
- (4) 2 Stop End (external)
- (5) 1 Gutter Outlet
- (6A) 2 Round Downpipe Brackets
- (7A) 1 Round Downpipe 2000mm
- (7B) 2 85mm Section of Pipe
- (8A) 1 Shoe
- (9) 2 Union Gutter Joiner
- (10) 2 Offset Bends
- 20 Self Tap Screws 10 3/4"
- (11) 1 Round Pipe Socket
- (7C) 1 Round Downpipe 500mm

